



ORDER NO. VMB-06 FLEXIBLE ARM WITH MAGNETEC BASE ORDER NO. VML-A **MAGNETIC BASE WORKING BEAM**

% FOR 20W/40W/60W 110V % FOR 20W/40W/60W 220V ORDER NO. VML-B **MAGNETIC BASE WORKING BEAM**

% FOR 20W/40W/60W 110V % FOR 20W/40W/60W 220V ORDER NO. VML-C **MAGNETIC BASE WORKING BEAM**

% FOR 20W/40W/60W 110V % FOR 20W/40W/60W 220V

*knob may vary & shape & color

If you would like to turn around the ARM of VMB series, don't rotate the ARM directly, because the thread in the base will be disintegrated, please loose the knob first (in the middle of ARM), then the ARM will be rotated, thanks!

After you set the position, Fix the Knob.

Before you set the new position, you must loose the knob.

Hold at the connection between Rod & Base to prevent thread breaking.

Hold the Mag. Base while moving & lifting

ORDER NO.	BASE SIZE LXWXH(MM)	HOLDING POWER	MAIN ROD O.D X L	WEIGHT (KGS)	CODE NO.
VMB-06	60X50X55	80KGS	Ø16X208	1.6	2015-610
VML-A	60X50X55	80KGS	Ø20X200	1.5	2015-611
VML-B	60X50X55	80KGS	Ø26X200	1.5	2015-612
VML-C	60X50X55	80KGS	Ø20X460	2.2	2015-616